

# SETUP INSTRUCTIONS

## Setting Up XRay Vision™ with XCam2™ Kit

### PLEASE READ

These instructions are intended to complement the instructions provided for each component in this kit. Please read each instruction sheet or manual provided.

**Important!** Use of the Video to USB Converter requires Windows 95 OSR2.1 with USB support or Windows 98. Do not plug in the Video Converter until the software is installed.

# 1

### Installing the XRay Vision Software

Before you connect the Video to USB Converter (model VA10A) you must first install the drivers and XRay Vision Software. First, download the XRay Vision server software from X10.com at:

<http://www.x10.com/xrv>

Next, run the Server installation application. Select the directory where XRay Vision will be installed and decide how you want XRay Vision listed on your Windows Start menu. After that, the XRay Vision installation program will automatically finish. You are now ready to set up the Video to USB Adapter.

# 2

### Connecting the USB Video Capture Adapter

When the installation program instructs you to, plug the Video to USB Converter connector into a USB port on your computer. The computer will recognize that new hardware has been installed and complete the installation.



# 3

### Setting Up the Camera

First set the transmission channel on the camera. Remove the rubber cap and use a paper clip to change the setting - A is

at the bottom, D at the top. Next, place or mount the XCam2 in the area you desire and connect it to the power supply. The camera is now transmitting.



# 4

### Connecting the Video Receiver to the Video Capture Adapter

1. Plug the yellow video plug on the supplied cable into the Video Out jack on the VR30A.
2. Connect the other end of the cable to the yellow Video In jack cable on the Video Capture Adapter.
3. Plug the PR30A power supply into any 120V AC outlet.
4. Plug the power output of the PR30A into the DC 12V plug on the VR30A.

Channel switch on the underside of the VR30A is set to the same letter as that on the XCam2.



# 5

### Installing XRay Vision Remote Viewer

After you have installed the XRay Vision server, you can use the XRay Vision remote viewer look at your images from any PC connected to the Internet. Once again you need to download the software from:

<http://www.x10.com/xrv>

This time choose the remote software. Run the file Remote installation application. and follow the installation instructions. You are now ready to connect up to your XRay Vision server and download images.



www.x10.com

MODEL  
NUMBER:  
IN25A

